

ROCK

RO 071..

RO 071K..

RO 075..

RO 085..


RO 081..

RO 081K..

RO 135..


RO 131..

RO 131K..



1


Montaggio Assembly




$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$



MIN - MAX



OK

2

a

071 071K 075




081 081K 085

131 131K 135

CH 30





b





C

071 071K 075
081 081K 085
131 131K 135



G 3/8"




ZSCA050..

d


071K..

081K..



131K..






2



3




075
085
135



F







Funzionamento
Working

081
081K
085



M

Manutenzione
Service






S Sostituzione Cartuccia
How to replace Cartridge

Sostituzione Aeratore
How to replace Aerator

a 071 071K 075
081 081K 085
131 131K 135

071 071K 075
081 081K 085
131 131K 135



Sostituzione Snodo
How to replace Joint

131 131K 135