

ZDUP

109..


110..

111..

112..


124..

125..



1


Montaggio Assembly



$65 \pm 5^\circ\text{C}$



$15 \pm 5^\circ\text{C}$




MIN - MAX




OK

2 a


109
111
124



3
a





110
112
125





112


b



110
125



c







F

Funzionamento
Working

109

111


124



110






112

125





Manutenzione
Service





Sostituzione Cartuccia
How to replace Cartridge

110

112

125

