

# EFFE ELLE

EF071 / EL071..

EF070 / EL070..

EF075 / EL075..

EF074 / EL074..

EF072 / EL072..

EF073 / EL073..

EF081 / EL081..


EF080 / EL080..

EF085 / EL085..

EF131 / EL131..


EF130 / EL130..

EF135 / EL135..



# 1


## Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$



MIN - MAX



OK

# 2

## a



071 070 075

074 072 073


081 080 085

131 130 135

## b



## c




070 075

072 073



080 085

130 135

**d**





071 070 075  
074 072 073  
081 080 085  
131 130 135







070 075  
072 073  
080 085  
130 135

e



# M


## Manutenzione Service



**S a**

Sostituzione Cartuccia  
How to replace Cartridge

071 070 075  
074 072 073  
081 080 085  
131 130 135




CH24

**c**

Sostituzione Snodo  
How to replace Joint

131 130 135



CH9

**b**

Sostituzione Aeratore

How to replace Aerator

071 070 075  
074 072 073  
081 080 085

